Special Tools for Torque Screwdrivers

Resin Handle for Torque Driver

Catalog No.	Color	Applicable Models
850	Orange	RTD120CN, LTD120CN, RNTD120CN, NTD120CN
851	Gray	
852	Black	
853	Green	
854	Red	
855	Blue	
856	Orange	RTD260CN, LTD260CN,RNTD260CN, NTD260CN
857	Gray	
858	Black	
859	Green	
860	Red	
861	Blue	

Resin Grip Dimensions	120CN		260CN	
	RTD/LTD	RNTD/NTD	RTD/LTD	RNTD/NTD
Hexagon width across flats max value [mm]	33		41	
Hexagone width across corner max value [mm]	35		44	
Length [mm]	67		81	68
Overall Length with torque screwdriver [mm]	130	110	150	110

Adjusting Tool for LTD/RTD

This tool is used for the torque adjustment (zero point) of LTD and RTD torque screwdrivers.

Catalog No.	Applicable Models
51	RTD/LTD15CN, 30CN
46	RTD/LTD60CN
1046	RTD/LTD120CN
47	RTD/LTD260CN
48	RTD/LTD500CN
49	LTD1000N

T-Handle for Torque Screwdrivers

This tool facilitates tightening with a large LTD screwdriver.

Catalog No.	Applicable Models
31	RTD/LTD/NTD/RNTD500CN
32	LTD/NTD1000CN
40	LTD2000CN
1031	RTDLS500CN
	RNTDLS500CN

Preset Hook Spanner For LTD/RTD/MNTD

This tool makes it easier to set the torque for mid to large capacity LTD and RTD screwdrivers. Used to adjust torque set on MNTD Marking torque driver.

Catalog No.	Applicable Models
52	RTD/LTD260CN,MNTD120CN
53	RTD/LTD500CN, MNTD260CN
54	LTD1000CN, MNTD500CN
55	LTD2000CN